



## **SureFire Start-Up & Check-Out Service Form** Hood Type Dishmachines. Model: Ensign 40-2

This checklist is designed to aid technicians in the proper start-up of an Insinger dishwasher. Many problems may be resolved by referring to the machine Tech Manual.

A. Ge	eneral- This section must be completed for all machines.
	1. Verify plumbing connections are as specified. This includes water, drains, steam and gas connections (if supplied). Refer to the installation drawing in the Tech Manual.
	<ol><li>Verify electrical connections are as specified (single point or multi-point). Refer to the machine name- plate and electrical ratings located in the control panel.</li></ol>
	<ol><li>Visually inspect the machine. Verify the installation is aesthetically correct. Refer any installation problem to the installers or end-user.</li></ol>
B. Ho	ood Type Dishmachines. Model: Ensign 40-2
	1. Close the drain.
	2. Turn Power ON.
	☐ a. Machine fills.
	□ b. Once full, the machine will automatically go through a wash and rinse cycle.
	<ol><li>Place a full dish rack in the machine, close the doors. The machine will automatically go through a wash and rinse cycle.</li></ol>
	☐ a. Wash cycle is 30 seconds, rinse cycle is 20 seconds. Pot washer wash cycle is 120 seconds.
	☐ b. Verify the pump motor is running I the proper direction.
	☐ c. Verify motor overload is adjusted to the proper amp draw according to the motor data plate.
	<b>4.</b> Verify temperatures and pressures. Tank temperature minimum is 156°. Final rinse mimimum is 180°. Final rinse flowing pressure is 20PSI. Adjust temperatures and pressures as necessary. Refer to the Tech Manual.
	5. Drain machine. Verify machine drains thoroughly.
C. Ins	stallation Information
Da	te of Start-Up: Service Tech:
Se	rvice Company:
Fa	cility:
Co	ontact: Phone #:
Мс	odel: S/N: RGA#:
Co	omments:

Please return this form to Insinger immediately:

**Technical Services Department Insinger Machine Company** 6245 State Road Philadelphia, PA 19135 800-344-4802 215-624-6966 fax insingermachine.com